#### **Slow Cooker**





## Slow Cooker SC 2395

Slow is good for you. With this slow cooker, everybody makes delicious stews, sauces, and soups, even the biggest dummy in cooking. Take all the ingredients, put them in your slow cooker, set the Delay Start button, turn it on, and 4 to 8 hours later, you have the most delicious stew. And this without stirring or even looking at it. Moreover, it is healthy since you don't need grease, and economical since even the toughest meat becomes soft like butter.

FRITEL, Tastefully Created!

# FAMILY COOKING SERIES

#### SC 2395

Article number 142114

EAN Code 5410585421148

- 5,5 L
- 210 Watt
- 45,5 x 33,3 x 24,5 cm
- •6,3 Kg

#### Unique product advantages

- Slow is more taste, more aroma, more for less money
- Deliciously simple, everyone can cook with a Slow Cooker
- Timer and display
  - Safety: The timer prevents the device from staying on for too long.
  - Time-saving: You can set the timer so the dish is ready exactly at the desired time.
  - Keep-warm function: Activates after cooking, keeping the food at the right temperature without further cooking, which is perfect if you want to serve your meal later.
  - Automatic shut-off: The timer ensures the slow cooker automatically turns off or switches to a keep-warm mode once the set cooking time has elapsed.
- Ideal for all dishes that need a long cooking time such as stews, soups, sauces
  - Cheaper: even the toughest meat turns super soft thanks to the slow and long cooking
  - More tasty: all aromas are kept
  - Healthier: you don't need any fat
  - Economical: ideal for cleaning up the fridge
- Ceramic bowl 5,5 L
  - Practical and removable
  - Beautiful to serve at the table
- Thanks to the large capacity you can prepare different portions at the time (5,5L)
- 4-8 persons

#### **Accessories**

FRITEL 135605 Cleaner for stainless steel





#### COOKING SERIES

# SC 2395

Article number 142114

EAN Code 5410585421148

- 5,5 L
- 210 Watt
- 45,5 x 33,3 x 24,5 cm
- 6,3 kg

## **Technical details**

- Diamond Design
- Thermostat knob with 4 positions:
  - Off
  - High (43-100°C)
  - Low (36-93°C)
  - Keep warm (28-48°C)
- Lid of tempered glass:
  - Almost unbreakable, shock proof
- COOL TOUCH handles
- Dishwasher proof: ceramic pot and glass lid
- Colour: black/chrome









